


Assembly Instruction (19146-438)

Art No.	Description
88888-1260	SP - Polar Dining Chair - Spin - Screw
88888-1245	SP - Polar Dining Chair - Spin - Turn plate
88888-1246	SP - Polar Dining Chair - Spin - Black leg
88888-1244	SP - Polar Dining Chair - Spin - Brown Seat



A	x1	B	x4	C	x1	D	x8	E	x1	F	x12	G	x4	
88888-1244		88888-1246		88888-1245		88888-1260								